



FIRE WIRE CAMERA DRIVER INSTRUCTIONS


Install the system software and hardware according to the instructions in the User's Manual included with the system. Once these tasks have been completed, the Fire Wire Camera driver must be installed in order for the camera to function. Begin by inserting the system CD into the CD-ROM drive. A screen resembling the one at right will appear. Click **Browse the CD**, as shown.



This will display the contents of the system CD, as shown at left. Double-click on the **Manuals** folder.



This will open a folder containing Fire Wire Camera Driver instructions that are specific to each compatible operating system. Double-click on the correct file and follow the instructions to install the Fire Wire Camera driver.



DOC-210
Rev. 1.0

Copyright © 2008
All Rights Reserved

MED Associates, Inc.
P.O. Box 319
St. Albans, Vermont 05478
www.med-associates.com